



Asus ZenWatch 2 Vibration Motor Replacement

A step-by-step guide in removing and replacing the vibration motor in the Asus ZenWatch 2.

Written By: Andrew



INTRODUCTION

Asus ZenWatch 2 users can set the watch to vibration mode if they want to receive notifications without an audible alert. The main component for this setting is the vibration motor housed within the casing of the watch. If the Asus ZenWatch 2 stops vibrating, this guide shows users how to replace it.



TOOLS:

- [T5 Torx Screwdriver](#) (1)
- [Heavy-Duty Spudger](#) (1)



PARTS:

- [Magnetic Project Mat](#) (1)

Step 1 — Vibration Motor



- Remove the watch strap by sliding the knob inward to detach from the face plate.

Step 2



- Open the watch by removing the four 3.5mm screws using the T5 screwdriver.

Step 3



- Place the spudger under the vibration motor and lift up to remove it from the watch.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-19 04:48:00 PM.